

Danfoss Icon™ Master Controller 24V



1. 1.1

1.2

1.3

1.4

1.5

2. 2.1

2.2

2.3

2.4

3. 3.1

3.2

4.1

4.2

5.

6.

7.

8.

9.

10.

Cable pin out

1	2	3
---	---	---

1. GND
2. COM A
3. COM B

11.

12.

13.

14.

15.

16.

17. Cable/wiring Danfoss Icon™ Master Controller 24V

24V	
2 x 2 x Ø 0,6 PDS cable (UTP or STP)	☺
H03VV-F 0,50 mm ² , flexible	☺
H03VV-F 0,75 mm ² , flexible	☺
3 x 1,0 mm ² , solid core	☺
3 x 1,5 mm ² , solid core	☺
5 x 1,5 mm ²	☹
> 1,5 mm ²	☹
< 24 AWG	☹

18.1

18.2

18.3