

**AFRISO**

AFRISO Sp. z o.o.
Szafsza, Kościelna 7
42-677 Czekanów
Poland / Polska / Polen /
Pologne / Польша

www.afriso.com
www.afriso.pl
www.afriso.de
www.groupeafriso.fr
www.afriso24.ru

BLH

801 / 850 / 822

Full operating manual / Pełna instrukcja / Vollständige Betriebsanleitung / Manuel d'utilisation complet /
Полная инструкция по эксплуатации

Scan QR code / Zeskanuj kod QR / Scanne den QR-Code /
Scannez le code QR / Отсканируй QR-код



Risk of scalding by hot medium! Perform all installation and maintenance work after the system has cooled down.

Ryzyko oparzenia gorącym medium! Wszelkich czynności montażowych i konserwacyjnych należy dokonywać po uprzednim wychłodzeniu instalacji.

Verbrennungsgefahr durch heißes Medium! Führen Sie alle Installations- und Wartungsarbeiten erst durch, wenn die Anlage abgekühlt ist.

Risque de brûlure par fluide chaud! Effectuer tous les travaux d'installation et d'entretien une fois que le système est refroidi.

Опасность ожогов от горячего теплоносителя! Все работы по монтажу и техническому обслуживанию выполняйте после остывания системы.

Security / Bezpieczeństwo / Sicherheit / Sécurité / Безопасность

	H_2O	max. 50% glycol		



Product / Produkt / Produkt / Produit / Продукт

Art. #					
90 801 10					
90 850 10	max. 4.0 m³/h	G1" F	PN 6	max. 90°C	max. 70 kW
90 822 00	max. 11.0 m³/h	G2" F	PN 10		max. 200 kW

Construction / Budowa / Konstruktion / Vue éclatée / Конструкция

BLH 801 	BLH 850 	BLH 822
--------------------	--------------------	--------------------

Mounting / Montaż / Montage / Montage / Монтаж



Maintenance / Konserwacja / Wartung / Entretien / Обслуживание

> 6 months
> 6 miesięcy
> 6 Monate
> 6 mois
> 6 месяцев

